EPICS Process Database

Michael Davidsaver

mdavidsaver@bnl.gov


EPICS Collaboration Meeting Fall 2010

Goals

- Understand .db file and IOC shell syntax
- Be able to follow the flow of a database
- Add/modify an alarm condition
- Add a calcout record to modify a value


- Examples
 - https://pubweb.bnl.gov/~mdavidsaver/training-201010.tar.gz

IOC Data Pipeline



- Configuration vs. Compilation
- Modular
- Database
 - Data (Configuration)
- Device Support
 - Operations
 - Modify DB
 - Access HW
 - Stateless (ideally)
- Driver Support
 - Catch-all

In the Database



Record

- Collection of fields
- Recordtype
- Many have devSup
- Fields
 - Atomic value (int, ...)
 - Scalar, array, or link
 - Attributes (eg. PP)
- Record+Field=Process Variable

In the Database

```
record(ai, "myrecord:v17") {
    field(DESC, "neat")
    field(DTYP, "mydev")
    field(INP, "#C1 S7 @v")
}
```

Record

- Collection of fields
- Recordtype
- Many have devSup
- Fields
 - Atomic value (int, ...)
 - Scalar, array, or link
 - Attributes (eg. PP)

Record+Field=Process Variable


RDB Translation

- Process DB is an object database with an integrated client (device support).
- In terms of a relational database
- recordtype → table
- record → row
- field → column
- link → foreign key (???)
 - FK is a cell (column+row) pointing to a row.
 - A Link is a cell pointing to another cell.

What is a record?

- A record is the basic unit of "action" in a database
- Field values modify the action

- Records do
- Fields store



Device Support

- Compiled (C/C++)
- Associated with a record
- Use pre-defined set of hooks


- API
 - report()
 - init()
 - init_record()
 - get_iointr_info()
 - process()
 - read()
 - write()

Db Syntax

- Recordtype
- Instance name
 - \$(P) macros expanded when loaded
 - Load same file several times
- Field name
- Field value
 - Always quote


```
record(ao, "$(P)name") {
	field(DTYP, "mydev")
	field(OUT, "#C$(C) S0 @")
	field(LINR, "LINEAR")
	field(ESLO, "0.1")
}
```

Simple recordtypes




- Analog (float)
 - ao, ai
- Binary
 - bo, bi, mbbo, mbbi
- Integer (32-bit)
 - longout, longin

Simple recordtypes



- Analog (float)
 - ao, ai
- Binary
 - bo, bi, mbbo, mbbi
- Integer (32-bit)
 - longout, longin


Simple recordtypes (2)



- Input
 - VAL=read(INP)
 - Operator reads VAL
- Output
 - Operator sets VAL
 - write(OUT,VAL)
- Address (INP/OUT)

Calculator Record

- recordtype: calcout
- 12 Input links (A-L)
- 1 Output link (OUT)
- Result stored in VAL
- CALC field
 - (A-B)/(A+B)
 - Length limit (40 char)
- Changeable at runtime
- OUT, OCALC, OVAL will be explained later




Calculator Record

- recordtype: calcout
- 12 Input links (A-L)
- 1 Output link (OUT)
- Result stored in VAL
- CALC field
 - (A-B)/(A+B)
 - Length limit (40 char)
- Changeable at runtime
- OUT, OCALC, OVAL will be explained later

```
record(ai, "bpm:up") {
record(ai, "bpm:down") {
record(calcout, "bpm:y") {
   field(INPA, "bpm:up")
   field(INPB, "bpm:down")
   field(CALC, "(A-B)/(A+B)")
```

Full list of CALC expression syntax in record reference manual

Calculator Record



```
record(ai, "bpm:up") {
record(ai, "bpm:down") {
record(calcout, "bpm:y") {
   field(INPA, "bpm:up")
   field(INPB, "bpm:down")
   field(CALC, "(A-B)/(A+B)")
```

Full list of CALC expression syntax in record reference manual

Exercise 1 – softloc Basics

- Executable: softloc
- Part of EPICS Base
- No device support

Useful utilities from EPICS Base caget, camonitor, caput, cainfo

The Counter

Start script: count.cmd
 dbLoadRecords("count.db", "P=myprefix")
 iocInit()
 Select your own

Simple 1 Hz counter
 softloc count.cmd

Things to try
 camonitor myprefix:count
 caput myprefix:count.SCAN
 ".1 second"
 caput myprefix:count.B -2

Full list of CALC expression syntax in record reference manual

Extending Counter

- Things to try
- Make the counter roll over

Use "cond? true: false"

Set limits

field(HOPR, "10") field(LOPR, "0")

- Examine CA metadata
- caget -d GR_DOUBLE myprefix:count
- caget -d GR_ENUM myprefix:count.SCAN
- caget -a myprefix:count

Database Scanning

- Cause processing
- When actions happen
 - Inputs read
 - Outputs written
 - Value conversion
 - Alarms checked
- Defined per record
 - SCAN field

- Conditions
 - Periodic timer
 - 1 second, 10 second, ...
 - HW interrupt
 - I/O Intr
 - Passive
 - More in a moment


Scan Examples

```
record(bi, "status..") {
                                        record(ao, "gain..") {
   field(SCAN, "1 second")
                                           field(SCAN, "Passive")
   field(INP, "some:other")
                                           field(DTYP, "mydac")
                                           field(INP, "#C1 S0 @gain")
record(ai, "level..") {
                              Device Support must
   field(SCAN, "I/O Intr")
                              know which "interrupt"
   field(DTYP, "myadc")
                              source to use
   field(INP, "#C1 S0 @adc")
```

Passive Scan

- Actions which can cause a Passive record to process
 - A 'Get'
 - A 'Put'
 - A forward link (more in moment)
- Things which can cause...
 - A DB link from another record
 - A CA client (another IOC, caget, EDM, BOY, ...)
 - The difference: None


Link Types



- PV Link
 - Connect to another field
 - Any field (almost)
 - Any IOC
 - Local or Remote link
- Hardware Link
 - Token for devSup
 - Identifies (card 7, port 2)

A Link is the least common denominator of a local function call and and CA get/put

Link Types (2)



- Output Link
 - Put data
 - write value to referenced field
- Input Link
 - Get data
 - Read value from referenced field
- Forward Link
 - Cause process()


A Link is the least common denominator of a local function call and and CA get/put

Constant Links

- Output
 - No action
- Input
 - Read a constant value (default 0)
 - Store in associated value field (INPA → A)

```
record(calcout, "bpm:y") {
    field(INPA, "bpm:up")
    field(INPB, "bpm:down")
    field(INPC, "14")
    field(CALC, "(A-B)/(A+B+C)")
}
```

Scanning and Links



- Link attributes (PP or NPP)
- Input Links
 - NPP Read current field value.
 - PP Process then read new field value
- Output Links
 - NPP Write field.
 - PP Write field then process using new value.
- Default is NPP

Process Passive Links

- field(INP, "name NPP")
 - Gets current value

- field(INP, "name PP")
 - If 'name' is SCAN
 Passive then process()
 - Gets new value

- field(OUT, "name NPP")
 - Sets new value


- field(OUT, "name PP")
 - Sets new value
 - If Passive then process()

Forward Links

- NPP Links transfer data
- PP Links transfer data and causes processing
- Forward links only causes processing
- Every record has 1 (FLNK)
 - fanout has 8

```
record(bi, "bit1") {
   field(SCAN, "1 second")
   field(FLNK, "bit2")
record(bi, "bit2") {
   field(FLNK, "bit3")
record(bi, "bit3") {
```

Link Types (3)



Record Processing Chains

- In most databases most records (~50%) don't belong to a processing chain.
- Processing chains are usually short (2-3 records).
- Most databases have a few longer chains.

Add process chain examples Pass 1 overview Pass 2 step through

Exercise 2 – Random numbers


 calc expressions can contain 'RNDM' to generate a uniform random number [0,1].

field(CALC, "RNDM")

- A Gaussian distribution can be approximated by summing 8 such numbers.
- What does '\$(P):sum' in gauss.db actually use.

Example 2 – Database

```
record(calc, "$(P):unif") {
  field(CALC, "RNDM")
  field(PREC, "1")
}
```




```
record(calc, "$(P):sum") {
 field(SCAN, "1 second")
 field(CALC, "A+B+C+D+E+F+G+H")
 field(INPA, "$(P):unif")
 field(INPB, "$(P):unif")
 field(INPC, "$(P):unif")
 field(INPD, "$(P):unif")
 field(INPE, "$(P):unif")
 field(INPF, "$(P):unif")
 field(INPG, "$(P):unif")
 field(INPH, "$(P):unif")
 field(PREC, "1")
 field(FLNK, "$(P):hist")
```

Alarms

- Each record has an alarm severity and status
- Severity: NO_ALARM, MINOR, MAJOR, INVALID
- Status: READ, WRITE, LINK, ...
- Conditions defined in record and device support
- Highest severity shown

Value Level Alarms

- For ao,ai, longout, longin
- Severity
 - NO_ALARM, MINOR, MAJOR, INVALID
 - Default: NO_ALARM
- Levels
 - HIHI, HIGH, LOW, LOLO



Value Level Alarms

- For ao,ai, longout, longin
- Severity
 - NO_ALARM, MINOR, MAJOR, INVALID
 - Default: NO_ALARM
- Levels
 - HIHI, HIGH, LOW, LOLO

```
record(ai, "my:adc") {
    field(HIGH, "14")
    field(HSV, "MINOR")
    field(LOW, "-12")
    field(LSV, "MAJOR")
}
```

Invalid Alarms


- For: ao, bo, calcout, mbbo, stringout
- IVOA
 - Continue Normally
 - Don't drive outputs Doesn't clip like DRVH DRVL
 - Set output to IVOV
- IVOV
 - Same type as VAL

```
record(ao, "my:dac") {
   field(HIGH, "255")
  field(HSV, "INVALID")
   field(LOW, "0")
   field(LSV, "INVALID")
  field(IVOA, "Set output
   to IVOV")
  field(IVOV, "0")
```

Exercise 3 – Sine

- Use a counter calcout and another calcout record to generate a sine wave.
- Set a minor alarm when >0.5 and a major alarm when <-0.7
- Use only one calcout for both count and sine (Hint: OCAL and OVAL fields)

Exercise 3 – Database



```
record(calcout, "$(P):sine:cnt") {
 field(SCAN, ".1 second")
 field(CALC, "A+B")
 field(INPA, "$(P):sine:cnt.VAL NPP")
 field(INPB, "0.01")
 field(OCAL, "sin(A)")
 field(OUT, "$(P):sine PP")
record(ai, "$(P):sine") {
 field(HIGH, "0.5")
 field(HSV , "MINOR")
 field(LOW, "-0.7")
 field(LSV , "MAJOR")
```

Link and Alarms

- Link attribute
 MS/NMS
- NMS (default)
 - Just get/put the value
- MS
 - Get/put value and alarm severity
- Propagate Alarms

```
record(ai, "one") {
  field(HIGH, "10")
  field(HSV, "MINOR")
record(ai, "two") {
  field(INP, "one MS PP")
  field(SCAN, "1 second")
```

Analog Scaling

- For: ao, ai
- Go from RVAL (integer) → VAL (float)
 - field(DTYP, "Raw Soft Channel")
 - Some other device support
- Players: LINR, ROFF, ASLO, AOFF, ESLO, EOFF
- VAL=(RVAL+ROFF)*ASLO+AOFF
- If LINR="LINEAR"
- VAL=ESLO*VAL+EOFF
- EGU="some string"

Analog Scaling Example

```
record(ai, "adc1") {
   field(DTYP, "myadc")
   field(ASLO, "0.1")
   field(AOFF, "10")
   field(ESLO, "")
   field(EOFF, "")
   field(EGU, "F")
```

- ADC calibration
 - 0.1 degrees/count
 - Count 0 is 10 deg. C
- C → F

Record Timestamps

- Each record has one timestamp
 - Shared by all fields
- Updated when processed
 - NOT when values change
 - Defaults to 0 (Jan. 1 1990) until first processed
- Problem for non-value fields
 - camonitor recname.SCAN
- Makes archiving these fields tricky

Controlling Timestamps

- Fields:
 - TSEL Timestamp selection input link
 - TSE Timestamp Event
 - TIME Stored time (Not directly readable)
- Choose where timestamp is taken from
 - Uses generalTime framework (>= 3.14.9)

Timestamp Selection

```
/* recGblTimeStamp() */
If TSEL is not CONSTANT
   if TSEL points to a TIME field
                                     Special hidden TSEL link option
                                            Takes time from record pointer
      TIME=dbGetTimeStamp(TSEL)
                                            or CA metadata
      return
   TSE=dbGetLink(TSEL)
                                Read an integer to use as the event number
if TSE != -2
                                            Takes time of last occurrence
   TIME=epicsTimeGetEvent(TSE)
                                            of event #
return
```

generalTime Events

- Normal events: 1-32k
 - Not database events
 - Hooks to event timing system (if present)
 - No default provider
- Special events
 - 0 Current wall clock time
 - -1 Best event time (???)
 - -2 Allow device support to set TIME

TS Examples (1)

- Current wall clock time
 - Default

```
record(ai, "name") {
...
}
```

 Specific gT event record(ai, "name") { field(TSE, "42") }

```
    From another record
        record(calc, "name") {
            field(INPA, "other.VAL")
                 field(TSEL, "other.TIME")
                 }
```

 Take event # from another record
 record(calc, "name") {
 field(TSEL, "other.TSE")
 }

TSEL and CA_LINK

- Potential mistake if 'aaa' and 'bbb' are in the same IOC.
- Example 1 (Wrong)
 - aaa.TSEL is DB_LINK
 - · 'aaa' and 'bbb' in same lock set
 - Timestamp may not match value
- Example 2 (Right)
 - aaa.TSEL is CA_LINK
 - 'aaa' and 'bbb' in different lock sets
- Rule: TSEL must use same type of link as value link.

```
record(calc, "aaa") {
   field(INPA, "bbb CPP")
   field(TSEL, "bbb.TIME")
             Copies latest
             From record struct
record(calc, "aaa") {
   field(INPA, "bbb CPP")
   field(TSEL, "bbb.TIME CA")
                     Uses meta-data
                     from previous
                     monitor/get.
```

Set Timestamp is Device Support

```
• Set TSE to -2
  record(ai, "aaa") {
    field(TSE, "-2")

    In dset

  read ai(aiRecord* prec) {
    if(prec->tse==epicsTimeEventDeviceTime) { /* -2 */
       prec->time.secPastEpoch=... /* Use EPICS Epoch (Jan 1 1990) */
       prec->time.nsec=...
```

Common Record Fields

- Device support: DTYP, INP, OUT
- Links: INP, OUT
- Scanning
 - SCAN, PINI, PACT
- Values: VAL, OVAL, RVAL, RBV, RRBV
- Alarms
 - STAT, SEVR
 - HIHI, HIGH, LOW, LOLO
 - HHSV (high high severity), HSV, LSV, LLSV
- Value+Alarm
 - IVOA (invalid out action), IVOV (invalid out value)
- Display: EGU, DRVH, DRVL